

## PRODUCT DESCRIPTION

**Programmable regulators** with RS232 or RS485 serial interface are designed to measure temperature and relative humidity of air, to measure concentration of CO<sub>2</sub> in air, to signal alarms and control of external devices. Regulators can be used in a chemical non-aggressive environment.

The CO<sub>2</sub> concentration is measured using the dual wavelength NDIR sensor with the multipoint calibration. This principle compensates aging of the sensing elements and offers maintenance free operation and outstanding long term stability.

The function of two output relays can be set from regulator keyboard (or from computer) and using the jumpers (see „Electrical wiring“). You can assign one of measured or computed value (dew point temperature, absolute humidity, specific humidity mixing ratio and specific enthalpy) to each relay. Setting of delay, hysteresis, audible alarm is enabled for each relay too. Devices are equipped with four button keyboard and two-line LCD display. The visual indication of the CO<sub>2</sub> concentration is provided by three LEDs to the left side of the display.

Regulators support Modbus RTU protocol and protocol compatible with standard Advantech-ADAM. For setting of all parameters you can use TSensor software (see [www.cometsystem.com](http://www.cometsystem.com)).

type *	serial interface	measured values	version	mounting	galvanic isolated output
H5321	RS232	CO <sub>2</sub>	probe on cable	wall	no
H5324	RS232	CO <sub>2</sub>	ambient air	wall	no
H5421	RS485	CO <sub>2</sub>	probe on cable	wall	yes
H5424	RS485	CO <sub>2</sub>	ambient air	wall	yes
H6320	RS232	T + RH + CO <sub>2</sub> + CV	ambient air	wall	no
H6321	RS232	T + RH + CO <sub>2</sub> + CV	probes on cable	wall	no
H6420	RS485	T + RH + CO <sub>2</sub> + CV	ambient air	wall	yes
H6421	RS485	T + RH + CO <sub>2</sub> + CV	probes on cable	wall	yes

\* models marked HxxxxZ are custom - specified devices

T...temperature, RH...relative humidity, CO<sub>2</sub>...concentration CO<sub>2</sub> in air, CV...computed values

## INSTALLATION AND OPERATION

The mounting holes and connection terminals are accessible after unscrewing the four screws in the corners of regulator and removing the lid. Devices have to be mounted on a flat surface to prevent deformation. Pass cables (external diameter 3 to 6.5 mm) through released glands and connect wires. Wire cross-section choose from 0.14 to 1.5mm<sup>2</sup>. The communication cables should be shielded. Do not forget to insert attached plugs into unused cable glands. The cables should be located as far as possible from potential interference sources. Unpack the external CO<sub>2</sub> probe and connect it to the device. Pay attention to mounting the device and probes, because incorrect choice of working position or place of measuring could adversely affect accuracy and long-term stability of measured values.

Actual parameters settings of each relay can be displayed by pressing of „▲“ key. To change any parameter, press the „Set“ key, enter password (default 0000) and set required value. Then click on „Set“ and pressing „Esc“ key exit setup mode. To change the password and to set all other parameters (acoustic alarm, limits of CO<sub>2</sub> indication, response to the error status, choice of communication protocol, select the computed value etc.) is used **Extended setting mode** (see manual for devices at [www.cometsystem.com](http://www.cometsystem.com)).

After switching the device starts internal test. During this time (about 20 s) LCD display shows ---- instead of CO<sub>2</sub> concentration value.

Devices don't require special maintenance. We recommend you periodical calibration for validation of measurement accuracy.

## COMMUNICATION PROTOCOLS AND ERROR STATES

Description of communication protocols you can download from [www.cometsystem.com](http://www.cometsystem.com). Device setting from the manufacturer is **ModBus RTU**, address 1, communication speed **9600 Bd** (no parity, 2 stop bits).

Device continuously checks its state during operation and if an error appears, it is displayed relevant code: **Err 1** – measured or calculated value (except the concentration of CO<sub>2</sub>) is over the upper limit, **Err 2** – measured or calculated value is below the lower limit or CO<sub>2</sub> concentration measurement error occurred, **Err 0, Err 3 a Err 4** – it is a serious error, please contact distributor of the device, **Err 5, Err 6** - there is problem with assigned value to output relay, **Err 9** – inserted password is not valid.

## SAFETY INSTRUCTIONS

- Don't use and don't store the devices without the cover of the temperature and humidity sensors.
- Temperature and humidity sensors have not to be exposed to direct contact with water and other liquids.
- It is not recommended to use the humidity regulators for long time under condensation conditions.
- Take care when unscrewing the filter cap as the sensor element could be damaged.
- Don't connect or disconnect devices while power supply voltage is on.
- Installation, electrical connection and commissioning should be performed by qualified personnel only.
- Devices contain electronic components, it needs to liquidate them according to currently valid conditions.
- **To complement the information in this data sheet** read the manuals and other documentations that are available in the Download section for a particular device at [www.cometsystem.com](http://www.cometsystem.com).



## Technical specifications

The relative humidity measuring range is limited at temperatures above 85°C see manuals for devices

ED calibration breyer by manufacturer) is limited at temperatures above 0°C, see standards of devices.

\*\* Recommended calibration intervals: concentration  $\text{CO}_2$  - 5 years, relative humidity - 1 year, temperature - 2 years.

\*\*\*\*\* It is recommended to switch off the LCD display at ambient temperature above 70°C